

DIM Design & Installation Manual

Facade on Wood – Swisspearl Patina NXT Design Line





Table of Contents

Swisspearl	4
The Self-ventilating Facade	6
Product Range	8
Installation	10
Profiles	21
Accessories	25
Storing and Handling	29
Care and Maintenance	30
Health and Safety	32
Onsite Handling	33

Swisspearl

Swisspearl

Swisspearl is one of the leading European manufacturers of multi-capability fibre cement building products. Our products and solutions add exciting new design opportunities for moulding attractive, durable settings for people's lives. But Swisspearl is more than mere products. We also help make all kinds of design and construction projects easier as well as more profitable, inspiring and effective. And for us, all construction also involves building relations with people, making your day better, and helping you make the day better for others.

Product Information

Swisspearl fibre cement is a modern building material made from natural and environmentally friendly raw materials. The technology has been developed by Swisspearl, having more than 90 years of experience within the manufacture of fibre cement. Our wide experience ensures a sustainable product which has accumulated all the advantages of fibre cement. The facade range can be used in all self-ventilated light weight facade constructions.

Featuring properties such as non-combustibility, sound and weather insulation as well as high impact strength, Swisspearl fibre cement boards are the ideal facade material.

Quality

Swisspearl product specifications and classifications comply with EN 12467:2012 and 13501-1:2007+ A1:2009

The facade range

- is manufactured in accordance with the quality management system ISO 9001:2015
- complies with the provisions set out in the Construction Products Regulation (EU) No. 305/2011

Product warranty

Warranty conditions are available on request from your local Swisspearl office or dealer.

Note!

The following limitations exist for the Swisspearl Patina design line

Do not use the following facade constructions: Sloped facade with deviation over 5 degrees from vertical, curved facade or non ventilated facade.

Disclaimer

The information and recommendations contained in this Design & Installation Manual ("DIM") are offered as a service to architects, constructors, installer and other persons involved with our products and are not intended to relieve them from their own responsibility. The information and recommendations provided herein are believed by Swisspearl Group to be accurate at the time of preparation of this DIM, or obtained from sources believed to be generally reliable. Swisspearl Group makes no warranty concerning the accuracy of the content of this DIM and shall not be liable for claims relating to any use regardless of whether it is claimed that the information or recommendations are inaccurate, incomplete, or otherwise misleading. The information and recommendations herein are intended to be used with the judgment and experience of professional personnel competent to evaluate the significance and limitations of the material contained. Swisspearl Group expressly disclaims any guarantees or warranties, expressed or implied, for anything described or illustrated herein and assumes no responsibility or liability for damages of any kind, including – without limitation – bodily harm, injury or damage to property inferred from this DIM or the use of the materials described herein.



The self-ventilating facade

A self-ventilating facade is a construction which helps minimise temperature variations in the wall throughout the year. Sunlight and heat are reflected away in the summertime, and insulation behind the facade boards reduces heat loss in lower temperatures.

At the same time, the natural ventilation passing through the construction minimises condensation.

The self-ventilating facade has additional features and benefits.

The most important benefit is the protection of the underlying construction against weather, wind and moisture. Some moisture passes through the facade, but it is limited to a level that can either be drained away or eliminated by natural ventilation.

The drainage feature of the system works when rainwater or moisture penetrates through the gaps in the facade. The moisture runs down either the reverse of the facade boards, the windstopper, or the insulation. There should be ventilation openings at the base of the structure and above doors and windows. These openings will also help drain the water away from the construction.

The natural ventilation works by means of a chimney effect. The air enters at the bottom of the structure and on its way up through the facade takes moisture-laden air through the ventilation openings at the top of the structure or at window or door openings.


The boards can be installed with open horizontal joints or with joint profiles. Horizontal joints contribute minimally to the natural ventilation and therefore, profiles can be used in these joints, if required.

Swisspearl recommends increasing the ventilation area behind the facade boards when installing facade boards on taller buildings. In the table below, it is showing the recommended minimum ventilation cavities behind the facade boards.

Cladding height	min. gravity
<6 m	20 mm
6-30 m	25 mm
>30 m	40 mm

Steel or timber framed construction

1. Swisspearl facade board
2. EPDM
3. Ventilated area minimum 20 mm
4. Timber batten minimum 20 mm wide
5. Cembrit Windstopper
6. Steel, timber framed construction with insulation or backwall




Ventilation air flow



Open joints




Joint profile




The self-ventilating facade

Ventilated Openings



Air is pulled into the construction through an opening at the base of the facade, and it must be ensured that unobstructed ventilation is possible throughout the facade's height. There should be a minimum free opening area of 15 mm, or equivalent 150 cm² per meter. If steel, aluminium or plastic perforated profiles are used, a ventilation area opening of minimum 150 cm² per meter is required. The opening at the base is also used to drain moisture that has entered the facade.



The passage of air must be maintained at the top of the facade whether it abuts a roof or other structure. Just as at the base, there must be a ventilation gap of a minimum of 15 mm or 150 cm² per meter.



A horizontal ventilation opening of minimum 15 mm or equivalent to 150 cm² per meter should be maintained beneath windows or other openings where a sill is used. This ventilation gap is usually formed between the top edge of the facade boards and the bottom edge of the sill. It is recommended that the sill projects a minimum of 30 mm beyond the front of the facade. This ensures that the water running from the sill does not enter the structure.




A horizontal free ventilation opening must be maintained above windows and doors as well. This ventilation gap must be at least 15 mm wide. If steel, aluminium or plastic perforated profiles are used, a ventilation area opening of minimum 150 cm² per meter is required. The opening at the base is also used to drain moisture that has entered the facade.


Product Range

The Swisspearl Patina NXT design line

Swisspearl Patina Original





Swisspearl Patina Rough



Swisspearl Patina Inline



Swisspearl Patina Structure



Directional grain

Swisspearl Patina's manufacturing process gives the boards a unique surface texture. This unique finish is enhanced by a process which adds a directional grain to the board - leaving the boards with a different appearance dependent on lighting and the angle of the board. By rotating boards within the facade makes it possible to obtain a playful visual effect - depending on the viewer's position and the lighting conditions.


Quick facts	Type	Fire class	Thickness	Dimensions	Weight/m2
Swisspearl Patina Original Swisspearl Patina Rough Swisspearl Patina Structure	Through coloured	A2,s1-d0	8 mm	1192x2500mm 1192x3050mm 1250x2500mm 1250x3050mm	14.9 kg/m ² *
Swisspearl Patina Inline	Through coloured	A2,s1-d0	9.5 mm	1192x2500mm 1192x3050mm 1250x2500mm 1250x3050mm	16.0 kg/m ² *

* Weights in this DIM are indicative only. Always refer to the Swisspearl Patina datasheet for valid values.



Installation

Substructure



Straightness of substructure

Fastening substructure

Anchorage of the substructure on the load-bearing wall must follow all local standards and regulations.

Before installing the substructure on the load-bearing wall, it should be checked by the installer to ensure that it is straight and the substructure can be mounted safely.

Make sure to choose the correct anchorage system for the substructure suitable for the material. Always install the anchoring according to the manufacturer of the system/ screw/bolt used.

Use the correct corrosion resistance according to the environment of the building's location.

Wind load calculations on how the substructure should be fixed to the load-bearing wall should be considered. This calculation will normally be done by a project/construction engineer.

Wood quality for substructure

Make sure that the quality of the wood used for the substructure follows country specific standards and regulations. Treated or untreated wood can be used for the substructure. The thickness is min 20 mm*
Width at joints min 100 mm
Width at middle batten 45 mm

Straightness of substructure


The horizontal tolerance of straightness for the substructure is +/- 3.0 mm measured with 2 meter straight edge.

The vertical tolerance of straightness for the substructure is +/- 1mm over 600 mm measured with straight edge.

*The minimum thickness of wood is 20mm, but the ventilation cavity depends on the height of the building, see page 6 for details.

Installation

Substructure



Installing 8 mm Swisspearl facade boards on timber frame

Max support distances:

629 mm o.c

Max screw centres: 600 mm o.c

For more information regarding wind load, please contact your local Swisspearl representative.

The following screws can be used for this solution:

Swisspearl Facade Wing Screw Wood, SCR-WW 4.9x38 mm

Swisspearl Facade Screw Wood, SCR-W 4.8x30/38/44 mm

Battens should be a minimum of 20 mm thickness to provide adequate ventilation.



Batten width should be minimum 100 mm for supporting battens, and 45 mm for central battens.

Typical panel joint is 8 mm, this allows panel scraps to be used as spacers. The maximum joint should not be more than 10 mm.

When using timber battens, always use Swisspearl EPDM with profiled ribs.

Swisspearl recommends using an EPDM of at least the same width as the selected batten. If untreated wood is used behind the board, it is advisable to use an EPDM that is 5-10 mm wider to better protect the wood.

Swisspearl facade boards can be installed on horizontal battens. When using horizontal battens for facade boards, a vertical counterbatten of 20 mm is required to provide the recommended ventilation. It is recommended to use aluminum profiles to close the vertical joints when using a horizontal substructure.



*wind load calculation assumes a Swisspearl Facade screw wood, SCR-W 4.8x38 mm or SCR-W 4.9x38 mm Wing Screw Wood

Installation

Edge distances

Edge distances

Fibre cement is an organic material that expands and contracts with changes in humidity. As a result, it is crucial to install the boards with the correct edge distances. If not properly installed, the strength of the board can be compromised, potentially leading to cracking at corners and edges. Therefore, always pre-drill the Swisspearl facade boards using an Ø8 mm drill bit suitable for fibre cement.


Horizontal and vertical installation

Swisspearl Patina design line

Edge distances side: 25 mm and up to Max 100 mm

Edge distances end: 80 mm and up to Max 100 mm

Note that the end distance (80 mm) follows the direction of the substructure.



Example of vertical substructure - Swisspearl Patina design line

Installation

Edge distances

Swisspearl Patina Inline

Swisspearl Patina Inline is available in four dimensions:
1192x2500/3050 mm
1250x2500/3050 mm

Please note that the 1192 mm and 1250 mm board cannot be combined as the widths of milled lines are slightly different.

Make sure to adhere to the installation principles in this manual when installing Swisspearl Patina Inline. The areas in which the installation of Swisspearl Patina Inline differs from the normal installation method will be explained below. Pre-drill the Swisspearl Patina Inline board using a Ø8 mm drill suitable for fibre cement.

Edge distances

The edge distance of the hole is dependent on the direction of the support system - as the normal installation principles.

- Edge distances from the board end, in the direction of the support system, should be minimum 80 mm up to max 100 mm
- The edge distance from the board side edges differs from the normal edge distance and should be minimum 30 mm and max 100 mm

If the board is mounted with horizontal lines as in fig. 3* the edge distance should be minimum 80 mm, but as the milled lines will not necessarily match the edge distance, it should be placed at the nearest following top line.

If the board is mounted with vertical lines as in fig. 3** the edge distance should be minimum 30 mm for full size boards. If cut to size, please refer to the paragraph below. Please note that the screw should always be mounted at the top of a line and centred (fig. 1). The same applies to the installation on central battens (fig. 2).

Edge distance of cut to size boards

If the board is cut to size to be installed in connection with windows, doors or similar, it may not be possible to keep the edge distance at 30 mm due to the nature of the lines. It will be necessary to place the screw at the following top instead (fig. 4).




Fig. 1. Swisspearl Patina Inline installation on intermediate batten.




Fig. 2. Swisspearl Patina Inline installation on intermediate batten.




Fig. 3. Swisspearl Patina Inline Edge distances.
Note! Min distance and/or the nearest following top line.




Fig. 4. Swisspearl Patina Inline installation of cut to size board.




Installation

Fixing points for Swisspearl facade boards

To make the installation on wood easier, Swisspearl facade boards can be installed using two fixing positions and all other positions should be sliding points. These positions should be as close to the board centre as possible and must be aligned horizontally.

When installing Swisspearl facade boards using screws, you must start with the fixing positions, followed by the sliding points above the fixing positions and finally the sliding points below (see illustration below)



X : Fixing position hole diameter Ø5 to 5.5 mm.







Illustration of correct screw installation. The fix points are marked with x.



Example: Horizontally mounted boards with four intermediate wood batten



Example: Vertically mounted boards with two intermediate wood batten



Example: Vertically mounted boards with one intermediate wood batten

Installation

Ceiling and soffit

Swisspearl facade boards is ideal for use in ceilings and soffits. The solution can be used for both exterior and interior applications.

The boards can be installed on a batten directly to a concrete deck or wooden structure, or they can be used as part of a solution with a suspended ceiling system.

One of the key advantages of using Swisspearl facade boards is that you can easily take down boards so you can reach any hidden installations as the boards are mounted using screws only.


Installing 8 mm Swisspearl facade boards on timber frame - as ceiling or soffit

Max support distances: 400 mm o.c

Max screw centres: 400 mm

The edge distances when using Swisspearl facade boards as ceiling or soffit are in principle the same as for facade boards in which the direction of the substructure and the orientation of the board define the edge distances. This also applies to hole sizes, joints and distances to other building materials.

Always use Swisspearl EPDM with ribs on timber battens.



Screw and batten distances

Fascia solution


Installing 8 mm Swisspearl facade boards on timber frame - as fascia boards

Max support distances: 629 mm o.c

Max screw centres: 600 mm

When mounting Swisspearl facade boards as fascia boards, boards below 300 mm width can be mounted directly using a 3 mm EPDM without ventilation battens behind the boards. When installing fascia boards of 300 mm width and more, it is necessary to keep a ventilation area behind the boards as with regular Swisspearl facade boards.

For both solutions, make sure to keep a 15 mm ventilation gap in both the top and the bottom of the fascia solution. Always use Swisspearl EPDM with ribs on timber battens.



Installation




Cut outs

To avoid cracking of the boards, when installing Swisspearl facade boards around windows, doors and other openings, ensure that the facade boards are installed correctly using Swisspearl's instructions.

Swisspearl recommends to avoid cutting single, exact apertures in boards, but instead you should cut smaller sections and install them individually.

Cut the boards and make vertical joints of 8mm. Make sure that there is support behind the joints, onto which the facade board can be mounted.

If the small cut outs are not wider than 100-150 mm, they can be mounted with only one rivet/screw in the middle of the board (a). This also applies when using the Swisspearl facade boards in other solutions on a building as window jambs or in connection with other narrow spaces.




Correct installation of Swisspearl facade boards at windows, doors and openings.

Incorrect installation of Swisspearl facade boards at windows, doors and openings.

Installation

General distances



Make sure to follow the guidance regarding distances described in this manual.


The facade board should finish between 10 and 30 mm below the bottom end of the sub structure. For overhang and similar, the maximum distance is 100 mm.

The distance to terrain from the bottom edge of the facade board should be a minimum of 150 mm.

The distance to flat roofs, balconies and other horizontal structures where the water can drain away can be a minimum of 50 mm.


Vertical clearance to profiles such as Swisspearl alu trim or Swisspearl Corner profile is minimum 4 mm. For horizontal clearances at windows and doors etc. leave a minimum of 10 mm for ventilation.

The clearance to other building materials is minimum 8 mm for movement and water drainage.



Installation

Details




External corner solution with open joint

Make an external corner solution without a Swisspearl corner profile.

There should be a vertical joint between the facade boards in the corner of minimum 4 mm.


Swisspearl recommends using a 100 mm EPDM and bend it around the corner to protect the wood.



Internal corner solution with open joint

When making an internal corner, there should be a vertical joint between the facade boards of minimum 4mm.

You can choose to either use 2x50 mm EPDM or a 100 mm EPDM and bend it around the corner to protect the wood.



Plinth construction/ bottom construction

Ensure that the facade board exceeds the substructure by 10-30 mm, allowing the water from the facade to drip of. Use a ventilation grill to ensure that bugs/vermin do not enter the construction behind the facade board.




Top construction

Make sure that the ventilation can move freely to the top of the construction. As for the rest of the ventilation gaps, there should be a minimum free opening area of 15 mm, or equivalent 150 cm² per meter.

There should be a minimum of 30 mm from the facade board front to the drip edge of the capping.


Installation

Details



Endings / Finishing

Behind the facade board, a ventilated batten of min 45 mm width should be installed and there must be a minimum of 8mm clearance to other building materials to allow for structural movements and proper water drainage and ventilation.




Window jamb

Swisspearl facade boards can be used for window jambs and returns.

Cut the facade boards to fit the depth of the window jambs. When mounting with one screw, the width of board should not exceed 200 mm.


If the depth is more than 200 mm, additional screws or a window U profile, into which the facade board can be inserted, must be used.

There should be a vertical joint of minimum 4 mm between the facade boards.



Window Sill

Swisspearl facade boards should not be used as sills. We recommend the use of formed aluminium or steel profiles. It is recommended that the sill projects a minimum of 30 mm beyond the face of the facade. There should be a minimum free open area of 15 mm, or equivalent 150 cm² per meter between the top facade board and the sill to ensure adequate ventilation behind the facade.





Window head

As with jambs, the window head can be formed using a Swisspearl board. At the front edge of the head detail, ensure a minimum free opening area of 15 mm, or equivalent 150 cm² per meter to ensure adequate ventilation behind the facade. Use a Swisspearl Ventilated Profile to ensure that insects/vermin cannot enter the construction behind the board. Please follow same details as for window jambs.

Profiles


Swisspearl offers a wide range of profiles to create weathertight and aesthetically pleasing facades. All Swisspearl Profiles are available in a variety of standard or special colours - either pre-painted or powder coated. The profiles are fixed using double sided tape and will be further fastened as the boards are installed. Most Swisspearl profiles are fabricated from 1 mm thick formed aluminium. For standard profiles, the profiles are pre-coated formed aluminium which has a gloss 30. For non-standard colours, the profiles are unpainted formed and powder coated aluminium with a paint of gloss 70. The profiles in standard colours are protected with a sticky foil.




1. Swisspearl External Corner Small
Length 3000 mm




2. Swisspearl External Corner Peak
Length 3000 mm



3. Swisspearl Internal Corner
Length 3000 mm




4. Swisspearl Vertical Trim Profile small
Length 3000 mm



5. Swisspearl Horizontal Trim Profile small
Length 3000 mm




6. Swisspearl Window Sill
Length 3000 mm



7. Swisspearl Caulking Profile
Length 3000 mm



8. Swisspearl Horizontal L Profile
Length 3000 mm



9. Swisspearl Drip Small
Length 3000 mm



10. Swisspearl Ventilated Profile
0.6 mm Perforated steel, Length 3000 mm


Profiles

Profile Use




Swisspearl External Corner Small is used for 90° external corner constructions, to a secure finishing detail. The profile is fixed using clout nails at 400-500 mm centres through pre-drilled Ø4 mm holes. Facade boards will help to hold the profile in place.

There should be a minimum 4 mm gap between the board edge and the profile.



Swisspearl External Corner Peak can also be used for 90° external corner constructions. It is installed in the same way as Swisspearl External Corner Small, using clout nails. The distance from the inside edge of the facade boards to the profile should be a minimum 2 mm.



Swisspearl Internal Corner is used for 90° internal corners. The profile is fixed using clout nails at 400-500 mm centres through pre-drilled Ø4 mm holes. There should be a minimum 4 mm gap between the board edge and the profile.




Swisspearl Drip Small is used to drain water away from the supporting structure or where neat detailing is required at the foot of the facade.

The profile can be used in conjunction with Swisspearl Ventilated Profile to ensure that insects and vermin or similar cannot enter the cavity behind the facade boards. There should be a minimum 4 mm gap between the board edge and the profile.


Profiles

Profile Use



To create appealing and neat window and door details use Swisspearl Vertical Trim profile on each side of the opening, and a Swisspearl Trim Horizontal profile as well as a Swisspearl Ventilated Profile. To achieve the best finish, trim the top edge of the vertical profile to match the angle of the outer face of the horizontal profile.

To provide sufficient ventilation, there should be a minimum of 15 mm gap between the horizontal profile and the edge of the facade boards.




At the window sills, use Swisspearl Window Sill. To ensure that water is properly drained from the structure, create a 30 mm upturned tab at each end of the profile and cut to neatly fit flush behind the vertical trim profiles. The Swisspearl Vertical Trim Profile is then fitted over the upturned sill tab. Underneath the window, a Swisspearl Ventilated Profile is installed to help stabilize the sill. There should be a 15 mm gap between the sill and the facade board to provide correct ventilation. It is also recommended that the front edge of the sill projects 30mm beyond the facade board.



Swisspearl Caulking Profile can be used with both vertical and horizontal joint profiles. It is not mandatory to use Swisspearl Caulking Profile, but it provides excellent joint solutions. The profile is installed in the same way as Swisspearl External Corner.

There should be a minimum 4 mm gap between the board edge and the Swisspearl Caulking Profile.




The Horizontal L Profile used for horizontal joints should be cut in the same length as the width of the facade board.




Accessories


All Swisspearl Facade Screws have mushroom heads with a torx 20 drive. Swisspearl Facade Screws are supplied as unpainted or in colours corresponding to the facade boards. It comes in two steel qualities, A2 and A4. A2 is the standard quality available in several lengths, whereas A4 steel quality is only available in one length.



Swisspearl Facade Screw wood
SCR-W 4.8x30 /38 /44 mm
A2 stainless steel
(Swisspearl Patina design line)



Swisspearl Facade Wing Screw wood
SCR-WW 4.9x38 mm
A2 stainless steel
(Swisspearl Patina design line)



Swisspearl Facade Screw wood
Without washer
SCR-W 4.8x40 mm
A4 stainless steel
(Swisspearl Patina design line)

Swisspearl EPDM 100 mm
For supporting battens



Swisspearl EPDM 3x100 mm
30m/roll Black

Swisspearl EPDM 50 mm
For centre battens



Swisspearl EPDM 3x50 mm
30m/roll Black

Accessories

Consumption of material


To be able to calculate the consumption of materials when installing Swisspearl facade boards, use the table below for reference. The consumption shown is per board.

Accessories per full sizes facade board						
Width		mm	1192		1250	
Length		mm	2500	3050	2500	3050
Thickness		mm	8	8	8	8
Coverage per board		m ²	2.98	3.64	3.13	3.81
Max distance – battens (o.c)		mm	600	600	629	629
Wall (Vertical mounted facade boards)	Facade Screw	pcs.	21	27	21	27
	EPDM 30/50mm	m	2.50	3.05	2.50	3.05
	Numbers of central battens	pcs.	1	1	1	1
	EPDM 90/100mm	m	2.50	3.05	2.50	3.05
	Numbers of supporting battens	pcs.	1	1	1	1
Wall (Horizontal mounted facade boards)	Facade Screw	pcs.	21	24	21	24
	EPDM 30/50mm	m	3.60	4.80	3.75	5.00
	Numbers of central battens	pcs.	3	4	3	4
	EPDM 90/100mm	m	1.20	1.20	1.25	1.25
	Numbers of supporting battens	pcs.	1	1	1	1
Soffit/Celling	Substructure distances	mm	400	400	400	400
	Facade Screw	pcs.	28	36	28	36
	EPDM 30/50mm	m	5.0	6.1	5.0	6.1
	EPDM 90/100mm	m	2.50	3.05	2.50	3.05

Swisspearl Blades

For cutting Swisspearl facade boards, the following blades can be used.

Diameter	Ø160	Ø190	Ø216	Ø250
Thickness mm	2.2/1.6	2.2/1.6	2.2/1.6	2.2/1.8
Centre hole mm	20	30	30	30
RPM	4800	4000	3500	3000
Teeth	6	4	6	14



Drill

For pre-drilling of Swisspearl facade boards, please refer to your local Swisspearl office for instructions.

Diameter 8 mm



Accessories

Swisspearl Facade Screws

Swisspearl Facade Screw

For Swisspearl Patina design line boards, you should use the Swisspearl Facade Screw.

For timber batten substructure, Swisspearl offers the SCR-W screw in three different screw lengths; 30 mm and 38 mm for one layer of boards and 44 mm for two layers of boards.

Pre-drilling

For pre-drilling, it is recommended that you use a drill bit Ø8 mm that is suitable for fibre cement (Fig. 2). This leaves you with the best results and the optimum number of drilled holes per drill bit.

Dust from cutting or drilling must be removed with a brush or compressed air immediately after the work has been completed, otherwise it can mark the surface of the boards.

Applying Swisspearl Facade Screws

Ensure that Swisspearl Facade Screws are centrally located in pre-drilled holes. The screw must be angled 90 degrees to the facade board.

When inserting the Swisspearl Facade Screw, please be careful not to overtighten the screw - especially near the edges and corners of the boards.

Swisspearl Wing Screw

If using Swisspearl Wing Screw SCR-WW (4.9x38 mm), no pre-drilling is necessary (Fig. 3). These screws are 'self-tapping' with cutting edges that create the correct hole diameter at the marked positions on the boards.

Screw quality

Swisspearl offers facade screws in A2 and A4 stainless steel. A2 is the standard choice for suburban or rural environments, while A4 is recommended for more demanding conditions, such as heavy industrial or coastal areas. Please note that the A4 screw is only available in one length for timber. To prevent surface contamination, screws should be cleaned regularly.

Maritime Conditions

Maritime conditions are typically defined as being within 1 km from the sea. The material specifications for the subframe, fasteners, and accessories should meet local standards for such environments. Ensure that the performance of the support system and accessories used complies with country-specific standards, approvals, and regulations.




Fig. 1




Fig. 2




Fig. 3

Accessories

Swisspearl Blade

To ensure a neat finish when cutting Swisspearl facade boards, it is important to use the correct blade. Swisspearl recommends using Swisspearl Blades as they have been customised for the purpose and leave you with the best end-result.

The blades have trapezoidal diamond teeth which provide excellent cutting quality and extremely long durability. In addition, the amount of dust generated is significantly reduced compared to similar blades.

The Swisspearl Blade is available in 4 sizes depending on which saw is used.

The Swisspearl blade can be used with dive saw, circular saw and stationary circular saw.

The Swisspearl Blade is a high quality product that can be sharpened, thus improving asset cost efficiency. To achieve the best quality cut and to know which side to cut from, make sure to follow the instructions shown here. The direction varies depending on which saw you use.


Handling

When cutting the facade boards, do not force the sawblade through the board. If you force the saw, the blade might overheat causing small vibrations -affecting the straightness of the cut or causing the board to flake if near the edges. The blade depth must be adjusted so that the blade goes max 10 mm through the board.


It is important to remove dust caused by cutting and drilling immediately either with a soft brush or a vacuum cleaner as it otherwise might damage the boards. Ensure that the boards are properly cleaned before installation, and if necessary use clean water, or water with a mild detergent and a soft sponge, or brush to remove dirt and dust from the surface.

Local requirements regarding safety must always be followed. Make sure to use correct safety equipment such as masks and dust ventilation and ensure that the saw is set up correctly according to the manufacturer's instructions.


Never use water when cutting Swisspearl facade boards.



When using a table saw, place the board with the face up -permost on the table and cut from the rear of the board.



When using a mitre saw, cut the board from the front.



When using a circular saw or dive saw, cut the board from the rear.

Storing and Handling

Swisspearl products are delivered with plastic protection cover. If undamaged, the plastic cover provides good protection against dust and weather conditions during transportation.



Always store Swisspearl products on a flat dry level surface.




Only two pallets must be stacked on top of each other. Make sure they are positioned so they stand securely and stable.



If the pallets are stored outside when they arrive at the building site, the plastic cover should be removed. The facade boards should be stored on the pallet or sleepers with max 500 mm distances.



Replace the plastic with a tarpaulin. It is very important that there is ventilation all around the tarpaulin and also on top of the pallet under the tarpaulin. This is done to make sure that condensation is reduced as much as possible.



If Swisspearl facade boards are stored more than 2-3 weeks on site, the pallets should be kept under a roof to ensure dry and ventilated conditions.



Do not drag products from the pallet, as it may leave permanent scratch marks. Lift the product by its narrow edge as it may break if handled incorrectly.

Care & Maintenance

On-site

Cleaning of boards after cutting and drilling

It is important to immediately remove dust caused by cutting and drilling from the front and rear of the boards with a soft brush/duster or a vacuum cleaner, as it otherwise might damage the boards. Ensure that the boards are properly cleaned before installation, and if necessary use clean water or water with a mild detergent and a soft sponge or brush to remove dirt and dust from the surface. Thereafter, wipe the boards with a damp cloth. It may also be necessary to wash the surface after installation if the building site conditions have been unfavourable. This is done with lots of clean water or water with a mild detergent and a soft sponge or brush and finally wiping the boards with a damp cloth.

Removal of calcium-based residues

Calcium carbonate residue may occasionally be seen on the board surface. This can be difficult to remove with water or even with detergents because it does not dissolve in water. For cleaning purposes 10% acetic acid (CH_3COOH) solution is used to dissolve the calcium compounds.

Note! Carefully observe safety precautions (MSDS) when working with acetic acid. R-phrases R36/R38 is valid: "Irritating to eyes, respiratory system and skin". Use proper clothing, nitrile rubber gloves, eye protection goggles and approved respirator (filter A, E or A/E).

Carry out the mixing outdoors. Apply the diluted 10% acetic acid solution evenly with a spray can to the surface of the stained board. Leave it to react for a few minutes. Do not allow the solution to dry, but rinse with lots of clean water. Repeat the process if necessary and rinse with water afterwards.

Note! Do not execute the cleaning process with acetic acid in direct sunlight or on hot surfaces. This might create permanent stains.

Cleaning of neighbouring areas

Windows and glass in particular but also other adjacent areas must be kept clean during the facade board installation and if necessary protected with plastic film. Alkaline leaching from cement bonded materials (dust from cutting or drilling holes in structural concrete, etc.) is prone to damaging glass and other materials. Therefore, frequent cleaning during and after the construction period is needed.

Surface damages and scratches

Damages and scratches should be avoided by lifting the boards off the pallet and handling them carefully during installation. Scratches might leave white streaks on the surface which will turn dark when exposed to rain, because the board absorbs water through the scratch. Repair paint is not available. In any case the dark area will diminish after 6 to 12 months, because of the carbonation reactions in the cement matrix of the board.

Behaviour in wet conditions

Since the boards are made of Portland cement, their colour may turn darker when exposed to rain if the board absorbs moisture through holes, scratches or insufficiently sealed edges. This is natural behaviour for any cement-based product and it does not affect the integrity or long-term durability of the board. The original colour is restored as soon as the boards dry out. The darkening will show after heavy rainfall for the first months after installation. It will gradually reduce within 6 to 12 months, because the cement-based matrix reacts with carbon dioxide from the atmosphere – carbonation – and thereby reduces water penetration.

Care & Maintenance

After installation

Annual Inspection

Normally Swisspearl facade boards do not require any maintenance. Weathering may however influence the appearance of the facade. Therefore, an annual inspection of the ventilation gaps, joints and fixings is a good idea.

Detection and repair of possible damage ensures a prolonged lifespan for the facade.

Cleaning

Swisspearl facade can be cleaned with cold or lukewarm water if necessary with the addition of a mild household cleaning agent not containing solvents. Always start from below with well-defined areas. Rinse with plenty of clean water until the facade is perfectly clean. Before cleaning full scale, it is recommended to test the chosen cleaning method on a smaller area to ensure it works and does not damage the board surface.

High-Pressure Cleaning

Warning! High Pressure Cleaning is a severe treatment for fibre cement facade. Exaggerated or wrong use of a high pressure cleaner may damage the surface. Therefore, High Pressure Cleaning is not recommended.

Moss & algae

Moss and algae growth can be removed with common agents available on the market. Care should be taken to ensure that the cleaning agent does not cause damage to the surface of the Swisspearl facade boards.

Confirm the compatibility of your cleaning agent with your cleaning agent supplier, and ensure it is applied according to the supplier's instructions. It is advised that before conducting a large-scale application a test is carried out on a small, inconspicuous area to ensure that the cleaning agent has no effect on the colour of Swisspearl facade boards.

Efflorescence

Efflorescence is a naturally occurring, white, powdery deposit that can appear on cement-based building materials (including bricks, cement walls, grout, and fibre cement). It is the result of a process in which moisture draws salt crystals to the surface, evaporates, and leaves a chalky substance behind. Efflorescence occurs when all three of the following conditions exist:

1. Water-soluble salts are present in the building material.
2. There is enough moisture in the wall to turn the salts into a soluble solution.
3. There is a path for the soluble salts to get to the surface.

Efflorescence may also be a sign of water ingress behind the facade. Make certain that all openings are properly covered and there is no water intrusion due to over-driven nails. While some efflorescence may weather away naturally on its own, it is best to take steps to treat it.

Efflorescence can be removed with household white vinegar and water. For most cases of efflorescence, Step 1 - 3 works well. But for substantial deposits of efflorescence go to Step 4.

For best results, follow these cleaning instructions:

1. Protect areas that are not to be cleaned. Rinse all plants and vegetation around the facade with water before and after application of the vinegar.
2. Generously coat the entire surface area with vinegar. Allow the solution to sit on the surface for 10 minutes.
3. Rinse the treated area thoroughly with water from the top down and allow the area to air dry.
4. For extra tough efflorescence:
Use a 10% acetic acid solution and apply to affected area with a cotton cloth. A light scrubbing with the cotton cloth may be required. After about 20 seconds rinse with water.

Health and Safety

As with all building materials, safety precautions must be taken into account and local laws and regulations must be observed.

Cutting and drilling

When cutting, grinding or drilling, dust from the fibre cement boards is released. This dust is characterised as mineral dust. Breathing large amounts of dust may cause irritation to respiratory functions, eyes or skin. Therefore, Swisspearl always recommends wearing personal protection equipment or stated by local law (Safety goggles, safety suit and a respiratory mask - P2 marked).

When cutting Swisspearl facade boards ensure adequate ventilation.



If the boards are cut indoors, it may be necessary to use an extractor system or a HEPA filter vacuum attachment attached to the power saw. When cutting outdoors, you should also use a HEPA filter vacuum attachment to the power saw. If ventilation is not adequate to limit exposure, wear a disposable respirator or air purifying cartridge respirator fitted with a Class P2 filter (European EN 143 standard). To reduce exposure to dust, Swisspearl recommends using Swisspearl Circular Blade.

Lifting Swisspearl facade boards

When lifting Swisspearl facade boards, please consider your lifting methods both in terms of safety but also to avoid damaging the boards.

When lifting or moving the facade board, please make sure to lift the board by its narrow edge as it may otherwise break if handled incorrectly.

If lifting Swisspearl facade board manually, make sure to adhere to any local rules. When lifting large boards, use mechanical lifting gear if possible. If this lifting gear uses suction/vacuum, be careful not to apply too much suction, as this may damage the surface or leave permanent marks.



Onsite Handling

Swisspearl facade boards are supplied with a polyethylene foam layer between each board to prevent scratching and damage to the surface. The polyethylene is an environmentally friendly polymer that can be disposed of as normal combustible waste.



When marking the boards, make sure that marks are no larger than the hole to be drilled or no thicker than the blade that is to cut the board, as it can be difficult to remove marks from the board afterwards.



Once boards are cut, you can bevel the cut edge with a fine grinder (80 grain) to give the edge a pre-cut finish.

The bevel should be angled at 45° relative to the board. This retains edge strength and removes small irregularities.



If not using Swisspearl Facade Wing Screws, the boards should be pre-drilled with an appropriate fibre cement drill bit.

Dust from cutting or drilling must be removed with a brush or a fiber cloth immediately after the work has been completed, otherwise it can mark the surface of the boards.







Swisspearl Group AG

Eternitstrasse 3
8867 Niederurnen
Switzerland
P: +41 55 617 11 60
F: +41 55 617 12 71
info@swisspearl.com

swisspearl.com